

Receiver



USB Connector


Top View



Left Click Button

Right Click Button

Scroll Wheel / Middle Button



### Front View



### Volume Controls



### Multimedia Buttons

