



BODY GLOVE

Earglove BlueSport™

QUICK REFERENCE GUIDE

To turn the unit on:

Flip the on/off switch to the on (I) position. The LED will flash green twice.

To initiate the pairing process:

The unit must be switched on. Press the pairing button until the LED light flashes green and red. To pair in hands-free mode, press the pairing button a second time. LED light will flash green and red at a faster tempo.

To answer a call or transfer a call from phone to earpiece:

Press the answer/end button once.

To end a call:

Briefly press down the answer/end button once or terminate the call from your cellular phone.

To adjust volume:

To increase the volume, press the volume up (+) button for each incremental level. To decrease the volume, press the volume down (–) for each incremental level.

To turn the unit off:

Flip the on/off switch to the off (O) position. The unit will instantly switch off.



BODY GLOVE

Australia

Benelux

Canada

France

Germany

Italy

Japan

Korea

Poland

Singapore

United Kingdom

United States

Fellowes[®]

1789 Norwood Avenue Itasca, Illinois U.S.A. 60143-1095

U.S. Customer Service: 1-800-945-4545

European Customer Service: 0080018101810

<http://www.fellowes.com>

<http://www.bodyglove.com>